


12' x 36' VARIO S64 FRAME ASSEMBLY

START HERE and assemble clockwise.



CENTER SUPPORTS DO NOT HAVE SCREEN SNAPS. THEY ARE NOT INTERCHANGEABLE WITH OTHER FRAME PARTS.

FRAME PARTS (w/snaps):

- (2) Top Corners
- (2) Bottom Corners
- (18) 110cm Sections
- (2) 66cm Sections
- (2) 27cm Sections

CENTER SUPPORT PARTS (w/o snaps):

- (1) 110cm Section
- (1) 98.5cm Top Section w/(1) Medium Crank (M8x50mm)
- (1) 98.5cm Bottom Section w/(1) Medium Crank (M8x50mm)
- (1) 66cm Section
- (3) Leg Clamps w/(9) Large Cranks (M8x85mm)

FRAME CRANKS:

- (26) for the Frame
- (3) for the Center Support
- (29) Total Vario Cranks Needed (M5x10mm)**

*** Send extra cranks, just in case

FRAME MUST BE ASSEMBLED EXACTLY AS SHOWN OR THE SCREEN WILL NOT LINE UP WITH THE SNAPS ON THE FRAME. CENTER SUPPORT IS FOR FRONT PROJECTION ONLY. DISREGARD ANY NUMERICAL SEQUENCE HAND WRITTEN ON FRAME PIECES; ASSEMBLE ONLY AS SHOWN IN THIS DRAWING.

Any S64 Legs can be used with this frame, but you must use the leg clamps included with the frame. This frame may come with a center leg for extra support when used with front projection.